



BERTHOLD Stock List

Part No : Connection Cable

Part No : Operating manual

Part No : LB6739W-11

Part No : LB6739-11

Part No : 55252-100

Part No : 55282 - S

Part No : 48456-11 LB 6752-11

Part No : 52595-100 8-10M

Part No : 52595-100

Part No : 50502-01-S

Part No : 58803-100-S

Part No : LB4700-11-00-80-a1-100

Part No : LB474-02-M

Part No : LB4700-11-00-80-A1-100 G23077

Part No : LB474-02-M GOST 20180-91

Part No : LB 474-02-M0

Part No : 56926-002

Part No : 64575